

nascom

Nascom RAM B 4Mhz / 48K Dynamic Memory Card

Constructional and Functional Specification

D O C U M E N T A T I O N

NM Part No. 024-300 Issue 3

The Nascom Microcomputers Division of Lucas Logic Limited reserves the right to amend/delete any specification in this brochure in accordance with future developments.

© Copyright Lucas Logic Limited

Nascom Microcomputers
Division of Lucas Logic Limited
Welton Road Wedgnoek Industrial Estate
Warwick CV34 5PZ
Tel: 0926 497733 Telex: 312333

Lucas Logic





Nascom Microcomputers

NASCOM type B RAM board: PCB modification

On issue 3 board, immediately adjacent to LK2, there will be found a wide track running along the edge of the board at right angles to the edge connector.

If only one through-plated hole is provided to connect the wide track to its counterpart on the other side of the board it is recommended that a piece of wire be soldered through the hole to provide greater current capacity.

Introduction

The RAM B is a Dynamic random access memory board. The memory may be configured to have a memory capacity of 16k, 32K or 48K bytes of user RAM. This on-board memory expandability is made possible by population options of either eight, sixteen or twenty-four MK4116 (16,384x1 MOS dynamic RAM) memories. The RAM B provides options for positioning the decoded memory space to start on any 4K address boundary. The RAM B also includes logic for a "Page mode operation" which permits up to four, fully populated, RAM B boards to be used in one system (192K in total).

This Manual contains all the information necessary to build, test and use your 4Mhz - 48K Dynamic RAM card. A separate Manual has been produced to cover the additional construction and use of the Page mode and Write protect upgrade kit (part no 024-110).

Section number	Title	Page number
1	Introduction for construction	1-1
	Component Check list	1-2
	Suggested order of construction	1-3
	Component placement	1-7
2	Memory test software	2-1
3	Specifications	3-1
	Circuit description	3-1
	Suggested memory map	3-4
	Memory array supply links	3-5
	Page mode links	3-6
	Addressing link options	3-6
	References	3-7
	Circuit diagrams	3-8
	Memory timing diagram	3-9

SECTION 1

Construction

1. Do not begin construction now. Read through all the documentation at least twice before starting in order to ensure that no fundamental and expensive errors are made.
2. Do not leave the MK4116 Dynamic RAM integrated circuits out of their antistatic packing. (see Nascom 1 or 2 Manual for MOS handling instructions).
3. Keep the box in which the RAM card was delivered in case it should have to be returned for repair.
4. Do not attempt to use too large a soldering iron. Use an earthed 15 to 25 watt soldering iron equipped with a suitably small bit. Use 22 Swg resin-cored solder.
5. Fit all components in the board on the same side as the printed information.
6. Be certain to fit all integrated circuits and tantalum bead capacitors in the correct locations and the correct way round.
7. Be certain to connect the power supplies to the Bus the correct way round. (See Nasbus functional specification, part No. 003-310).
8. Do not attempt to remove or plug in integrated circuits on the board or perform any soldering while the power supply is switched on.
9. If any difficulty is experienced when plugging an IC into its socket do not use extreme force. If in doubt remove the IC; check that the pins are straight and parallel and start again. An IC insertion tool may be found useful. Note that all ICs are manufactured with the leads spread apart by a few degrees to suit mechanised handling equipment. They can be bent parallel with care using small pliers or one row at a time by pressing down sideways on a flat surface. There should be no bend in the leads and they should be at right angles to the body.
10. Before switching on any power supplies, hold the board up against a powerful lamp and inspect both sides with a magnifying glass for solder splashes, unsoldered joints, incorrectly orientated components and bent IC pins. (To check for the latter look at all ICs end on). TAKE TIME OVER THIS.

11. The following tools are needed:-

- (a) Long nose pliers
- (b) Side cutters
- (c) 15 to 25 watt soldering iron
- (d) A damp sponge or cloth - to keep iron bit clean
- (e) A powerful light source
- (f) A magnifying glass - for inspecting the PCB
- (g) A multimeter - not necessary, but useful to check supplies

COMPONENT LIST

No.	Part No.	Qty	Description	Circuit ref.
INTEGRATED CIRCUITS				
01	501-244	4	74LS244 Octal Tri-state buffer	IC25 to 28
02	501-075	1	74LS75 Quad latch	IC29
03	501-156	2	74LS156 0'c 2 to 4 decoder	IC30 & 31
04	502-074	1	74S74 Schottky dual D-type flip-flop	IC32
05	503-157	2	74157 TTL Quad 2 to 1 multiplexer	IC33 & 34
06	501-020	1	74LS20 Dual 4 input Nand gate	IC35
07	501-008	2	74LS08 Quad 2 input And gate	IC36 & 41
08	501-032	2	74LS32 Quad 2 input Or gate	IC37 & 38
09	503-006	1	7406 TTL 0'c Hex inverter	IC39
10	501-279	1	74LS279 Quad reset/set latch	IC40
11	501-004	1	74LS04 Hex inverter	IC46
12	601-900	1	54-018 Polara 150ns active delay line	IC47
MEMORY				
13a	024-100	8	MK4116 Dynamic RAM / 16K kit	IC1 to 8
13b	024-101	16	MK4116 Dynamic RAM / 32K kit	IC1 to 16
13c	024-102	24	MK4116 Dynamic RAM / 48K kit	IC1 to 24
RESISTORS				
14	614-100	1	899-3-R33 33R resistor pack	RP1
15	614-103	1	899-3-R47 47R resistor pack	RP2
16	614-101	1	898-1-R4.7K 4K7 resistor pack	RP4
17	614-102	1	899-3-R4.7K 4K7 resistor pack	RP5
18	510-272	6	2K7 .25watt red - violet - red	R1 to 6
19	510-102	4	1K .25watt brown - black - red	R7,8,9,14
20	510-221	4	220R.25watt red - red - brown	R10 to 13

RESISTORS Cont

21	510-220	1	22R .25watt red - red - black	R15
----	---------	---	-------------------------------	-----

CAPACITORS

22	609-127	1	10uF Tantalum bead 25v	C78
23	609-110	6	2uF2 Tantalum bead 35v	C74 to 76 & C80 to 82
24	520-104	48	100n Ceramic disc	C1 to 48
25	520-103	24	10n Ceramic disc	C49 to 69 71, 72 & 77
26	520-330	2	33pf Ceramic disc	C70 & 79

IC SOCKETS

27	705-104	6	20 pin .3 inch DIL
28	705-102	31	16 pin .3 inch DIL
29	705-101	15	14 pin .3 inch DIL

MISCELLANEOUS

30	705-113	1	20 pin header plug .3 inch DIL	SKT 1
31	710-100	1	77 way Nasbus connector	PL 1
32	024-200	1	RAM B PCB	

SUGGESTED ORDER OF CONSTRUCTION

1. Unpack the kit and check the contents against the parts list. Return the memory ICs to their antistatic packing immediately after checking. Inspect the printed circuit board (PCB) for any signs of damage.


2. RESISTORS Preform the leads of the 15 resistors to a separation of 1/2inch (12.7mm). Some resistors may be supplied already formed. Insert the resistors into the card. Components may be held in place after insertion by bending the leads about 40 degrees in the opposite direction. Solder the resistors.

3. IC SOCKETS Check to see that all the IC sockets do not have their pins bent or missing. During insertion take care not to bend any pins. When soldering the IC sockets it may be a good idea to solder only two pins on opposite corners to begin with. Then turn the board over again and check that the sockets are flat on the board, straight and also correctly oriented. See figure 1 for typical socket orientation marks. Any necessary alterations may now be carried out with ease, as only two pins are soldered.

fig.1a Pin 1 on PCB Legend.




fig.1b Typical orientation marks viewed from above, pins facing away from you. Pin 1 is the top left hand corner in each case.



4. CAPACITORS Insert and solder:- (1) The 48, 100n ceramic capacitors, located near the memory array which are C1 to C48. (2) The 24, 10n ceramic capacitors. (3) The 2, 33pf ceramic capacitors which are C70 and C79. (4) And finally the tantalum capacitors. These are electrolytic capacitors and as such must be correctly orientated (see fig.2), C78 is 10uF. C74 to C76 and C80 to C82 are 2.2uF.

fig.2



5. Using offcuts from the resistors or capacitors, solder in position the test points marked with a square on the PCB. The GND (0v) test point is located near the 77 way edge connector. The remaining test points are located near the opposite edge of the PCB. These test points are, from left to right WR EN, RD EN, MUX, WR2, WR1, RAS0, CAS, RAS2, WR0 and RAS1. Crop the leads on the component side of the board leaving about 3/8ths inch or enough lead to enable test hooks to be hooked onto them. Crop the leads on the circuit side.

6. LINKS If the "Page mode and write protect upgrade kit" is not installed and memory type MK4116 is used wire the links as shown overleaf:-

LK1 c to 2
 LK2 c to 2
 LK3 c to 2
 LK5 c to 1
 LK6 c to 2
 LK7 leave out

If the upgrade kit is installed and memory type MK4116 is used wire the links as follows:-

LK1 c to 2
 LK2 c to 2
 LK3 c to 2
 LK5 c to 2
 LK6 c to 1
 LK7 wire in link

Please note that incorrect positioning of LK1,2 and 3 may result in the memory being damaged. For further information on link options refer to section 3-4 of this manual. Finally, a link should be inserted in each of the three switch pads (SW1 to 3) when the upgrade kit is not used, as illustrated below.

fig.3 Write protect Switch Links



SW3



SW2



SW1

6. ADDRESS DECODE Insert the 20 pin header plug into SK1. One corner of the plug has a notch in it, this is pin 1. It is suggested that the address decode links are soldered onto the header while inserted into SK1. This will maintain the pin alignment while the pins are hot. Refer to section 3-5 of this manual and wire in position the decode links on the header plug.

7. INTEGRATED CIRCUITS Insert the resistor packs and ICs in the following sequence:-

- | | | |
|------|---------------------|---|
| (1) | RP1..... | 899-3-R33 |
| (2) | RP2..... | 899-3-R47 |
| (3) | RP4..... | 898-3-R4.7 |
| (4) | RP5..... | 899-3-R4.7K |
| (5) | IC25 to 28..... | 74LS244 |
| (6) | IC33 & 34..... | 74157 |
| (7) | IC39..... | 7406 |
| (8) | IC46..... | 74LS04 |
| (9) | IC32..... | 74LS74 |
| (10) | IC36 & 41..... | 74LS08 |
| (11) | IC29..... | 74LS75 |
| (12) | IC35..... | 74LS20 |
| ** | (13) IC47..... | 54-018 |
| | (14) IC37 & 38..... | 74LS32 |
| | (15) IC40..... | 74LS279 |
| | (16) IC30 & 31..... | 74LS156 |
| | (17) IC1 to 8..... | MK4116 for 16K bytes
of memory |
| | | IC1 to 16.....MK4116 for 32K bytes
of memory |
| | | IC1 to 24.....MK4116 for 48k bytes
of memory |

** IC 47 (the delay line) has pin 1 indicated by a white dot.

When completed, check that ICs are correctly orientated and in the right place.


8. Take a final look at the card and check that there are no unsoldered pins or solder bridges anywhere.

9. When satisfied everything is correct, plug the board into the system. Power up the system and, if a multimeter is available, check the supply voltages. Check Nascom 1 or 2 for Normal operation.

10. Enter the machine code "Memory test" program which may be found in section 2 page 1.

-----oooo00oooo-----

fig.4 Component placement RAM B 026



SECTION 2

1. MEMORY TEST PROGRAM.

This program is designed to run under Nas-sys on a Nascom 1 or 2. The program is split into two halves, part 1 executes three tests giving the following error letter if the condition is not met :-

A - Location not set to zero
 B - Walking bit test
 C - location not set to FF

Part two of the program loads a jump instruction into each location and then executes it, moving the jump through the memory as it goes. If the program "crashes" because of a fault in memory the screen will hold the last address, or if this is cleared or corrupted locations 0D49 & 0D4A will still contain it. The program will loop till a system reset or fault occurs.

Execute 0C80 ssss eeee . Where ssss is the first location and eeee is the last location of memory to be tested.

ZEAP Z80 Assembler - Source Listing

```

                                0290 ; NAS-SYS EQUATES
0C0E                          0300 ARG2 EQU #0C0E
0C10                          0310 ARG3 EQU #0C10
0C29                          0320 CURSOR EQU #0C29
0018                          0330 SCAL EQU #18
0028                          0340 PRS EQU #28
0030                          0350 ROUT EQU #30
0066                          0360 TBCD3 EQU #66
0068                          0370 B2HEX EQU #68
0069                          0380 SPACE EQU #69
006A                          0390 CRLF EQU #6A
000C                          0400 CS EQU #0C
000D                          0410 CR EQU #0D
                                0420 ;
                                0430 ;
                                0440 ;
0C80                          0450 ORG #0C80
0C80 EF                       0460 RST PRS
0C81 0C                       0470 DEFB CS,0
0C83 EF                       0480 LOOP RST PRS
0C84 4D                       0490 DEFM /MEMORY TEST PART 1/
0C96 0D                       0500 DEFB CR,0

```

0C98	2A100C	0510		LD	HL,(ARG3);FINISH ADDR
0C9B	AF	0520		XOR	A
0C9C	ED5B0E0C	0530		LD	DE,(ARG2);START ADDR
0CA0	ED52	0540		SBC	HL,DE ;CALC COUNT
0CA2	E5	0550		PUSH	HL ;COUNT ON STACK
0CA3	44	0560		LD	B,H
0CA4	4D	0570		LD	C,L ;AND IN BC
0CA5	2A0E0C	0580		LD	HL,(ARG2)
0CA8	E5	0590		PUSH	HL ;START ADDR ON STACK
0CA9	54	0600		LD	D,H
0CAA	5D	0610		LD	E,L ;AND DE
0CAB	13	0620		INC	DE ;READY FOR LDIR
0CAC	3600	0630		LD	(HL),0 ;ZERO THE 1st LOCATION
0CAE	EDB0	0640		LDIR	;AND COPY IT THROUGH
0CB0	E1	0650		POP	HL ;START ADDR BACK
0CB1	C1	0660		POP	BC ;AND COUNT
		0670			;CHECK FOR ZERO'S
0CB2	1600	0680	ZCHK	LD	D,0 ;CLEAR ERROR FLAG
0CB4	AF	0690		XOR	A ;CLEAR A
0CB5	BE	0700		CP	(HL) ;MEMORY SHOULD BE ZERO
0CB6	3E41	0710		LD	A,"A ;LOAD ERROR LETTER IN
					CASE
0CB8	C4390D	0720		CALL	NZ,ERR ;FAULT A IF NON-ZERO
		0730;			-----WALKING BIT TEST
0CBB	3E01	0740		LD	A,1 ;INITIAL BIT POSITION
0CBD	77	0750	WALK	LD	(HL),A ;PUT IT IN MEMORY
0CBE	BE	0760		CP	(HL) ;DID IT GET THERE
0CBF	F5	0770		PUSH	AF ;SAVE BIT PATTERN
0CC0	3E42	0780		LD	A,"B ;LOAD ERROR LETTER IN
					CASE
0CC2	C4390D	0790		CALL	NZ,ERR ;FAULT B IF WALK FAILS
0CC5	F1	0800		POP	AF ;BIT PATTERN AND FLAGS
0CC6	2003	0810		JR	NZ,ALFF ;IF IT FAILED DO NEXT
					TEST
0CC8	17	0820		RLA	;WALK BIT ACROSS
0CC9	30F2	0830		JR	NC,WALK ;UNTIL IT REACHES
					CARRY
		0840;			-----LOAD FF TEST
0CCB	3EFF	0850	ALFF	LD	A,#FF
0CCD	77	0860		LD	(HL),A
0CCE	BE	0870		CP	(HL) ;DID IT GET THERE
0CCF	3E43	0880		LD	A,"C ;LOAD ERROR LETTER IN
					CASE
0CD1	C4390D	0890		CALL	NZ,ERR ;FAULT C FF NOT LOADED
0CD4	7A	0900		LD	A,D ;GET ERROR FLAG
0CD5	B7	0910		OR	A ;NON-ZERO IF ERROR
					OCCURED
0CD6	C4460D	0920		CALL	NZ,NEWLIN
0CD9	EDA0	0930		LDI	;STEP ON TO NEXT
					LOCATION
0CDB	EAB20C	0940		JP	PE,ZCHK ;LOOP TILL END REACHED

```

0950;-----PART TWO
0CDE EF 0960 RST PRS
0CDF 0D 0970 DEFB CR
0CE0 50 0980 DEFM /PART 2 OP-CODE FETCH TEST/
0CFA 0D 0990 DEFB CR,0
0CFC 2A100C 1000 LD HL,(ARG3)
0CFF AF 1010 XOR A
0D00 ED5B0E0C 1020 LD DE,(ARG2)
0D04 ED52 1030 SBC HL,DE ;CALC COUNT
0D06 44 1040 LD B,H
0D07 4D 1050 LD C,L ;COUNT IN BC
0D08 0B 1060 DEC BC
0D09 0B 1070 DEC BC ;MAKE ROOM FOR JP
0D0A EB 1080 EX DE,HL ;HL=ARG2
0D0B E5 1090 OLOOP PUSH HL ;START ADDR
0D0C 3EC3 1100 LD A,#C3
0D0E 77 1110 LD (HL),A
0D0F 23 1120 INC HL ;PUT JP IN MEMORY
0D10 11270D 1130 LD DE,RETURN
0D13 73 1140 LD (HL),E
0D14 23 1150 INC HL
0D15 72 1160 LD (HL),D ;FOLLOWED BY ADDRESS
0D16 E1 1170 POP HL ;GET START ADDR BACK
0D17 ED5B290C 1180 LD DE,(CURSOR);GET CURRENT CURSOR
0D1B C5 1190 PUSH BC ;SAVE COUNT
0D1C DF 1200 RST SCAL
0D1D 66 1210 DEFB TBCD3 ;PRINT CURRENT ADDR
0D1E 22490D 1220 LD (STORE),HL ;SAVE ADDR WE MAY BOMB
0D21 ED53290C 1230 LD (CURSOR),DE;REPLACE OLD CURSOR
0D25 C1 1240 POP BC ;GET COUNT BACK
0D26 E9 1250 JP (HL) ;JUMP TO TEST RAM
0D27 EDA0 1260 RETURN LDI ;RETURN HERE HOPFULLY
0D29 EA0B0D 1270 JP PE,OLOOP;LOOP TILL DONE
0D2C EF 1280 RST PRS
0D2D 4C 1290 DEFM /LOOPING/
0D34 0D 1300 DEFB CR,0
0D36 C3830C 1310 JP LOOP
1320;-----ERROR ROUTINE
0D39 F5 1330 ERR PUSH AF ;SAVE FLAGS
0D3A F7 1340 RST ROUT ;OUTPUT ERROR LETTER
0D3B DF 1350 RST SCAL
0D3C 69 1360 DEFB SPACE ;AND SPACE
0D3D C5 1370 PUSH BC ;SAVE COUNT
0D3E DF 1380 RST SCAL
0D3F 66 1390 DEFB TBCD3 ;OUPUT ADDR
0D40 C1 1400 POP BC
0D41 DF 1410 RST SCAL
0D42 69 1420 DEFB SPACE
0D43 14 1430 INC D ;SET ERROR FLAG

```

0D44	F1	1440	POP	AF	
0D45	C9	1450	RET		
0D46	DF	1460	NEWLIN	RST	SCAL
0D47	6A	1470	DEFB	CRLF	
0D48	C9	1480	RET		
0002		1490	STORE	DEFS 2	;SPACE FOR ADDR

Memory test object code listing

```

0C80 EF 0C 00 EF 4D 45 4D 4F 52 59 20 54 45 53 54 20
0C90 50 41 52 54 20 31 0D 00 2A 10 0C AF ED 5B 0E 0C
0CA0 ED 52 E5 44 4D 2A 0E 0C E5 54 5D 13 36 00 ED B0
0CB0 E1 C1 16 00 AF BE 3E 41 C4 39 0D 3E 01 77 BE F5
0CC0 3E 42 C4 39 0D F1 20 03 17 30 F2 3E FF 77 BE 3E
0CD0 43 C4 39 0D 7A B7 C4 46 0D ED A0 EA B2 0C EF 0D
0CE0 50 41 52 54 20 32 20 20 4F 50 2D 43 4F 44 45 20
0CF0 46 45 54 43 48 20 54 45 53 54 0D 00 2A 10 0C AF
0D00 ED 5B 0E 0C ED 52 44 4D 0B 0B EB E5 3E C3 77 23
0D10 11 27 0D 73 23 72 E1 ED 5B 29 0C C5 DF 66 22 49
0D20 0D ED 53 29 0C C1 E9 ED A0 EA 0B 0D EF 4C 4F 4F
0D30 50 49 4E 47 0D 00 C3 83 0C F5 F7 DF 69 C5 DF 66
0D40 C1 DF 69 14 F1 C9 DF 6A C9 00 00 00 00 00 00

```

Upon execution of the above program the VDU should output the following message if the Memory card is functions correctly.

MEMORY TEST PART 1

PART TWO OPCODE FETCH TEST
 xxxx (rapidly changing addresses)
 LOOPING

This message will be repeated until either a fault condition arrises or a system reset is performed.

However if the Memory card is faulty the VDU would output a message similar to the example below;-

```

MEMORY TEST PART 1
A aaaa B bbbb C cccc
A aaaa B bbbb C cccc
A aaaa
A aaaa
A aaaa B bbbb
A aaaa B bbbb C cccc

```

PART 2 OPCODE FETCH TEST
 eeee

Where aaaa is a location in memory that will not set to zero, bbbb will not accept certain data patterns, cccc will not set all bits high & eeee was the last address that did not accept a jump command.

Memory test program copyright c 1980 CC Soft.

DBDR Data bus drive determines the direction of the bidirectional data bus buffers on the buffer card. Low to drive data to the Nascom. Not used by Nascom 2.

The following circuit description should be read in conjunction with the circuit diagrams to be found near the end of this manual.

3. ADDRESS and DECODE LOGIC Address lines A0 to A11 are buffered by ICs 27 and 28 (Schottky Schmitt). Buffered address lines A0 to A13 are routed to address switches IC33 and 34, where they are switched into the memory array to provide row (A0 to A6) and column (A7 to A13) addresses. The row and column addresses are strobed into the memory by two negative going clocks called Row address strobe (RAS) and column address strobe (CAS). By the use of RAS and CAS the address bits are latched into the memory for access to the required memory location. Because the Z80 CPU does not guarantee that the address bus will hold valid information past the rising edge of MREQ on an Op-code fetch, A12 to A15 are latched (IC29) each time MREQ is active. This prevents glitches appearing on the RAS lines. A12 to A15 are decoded in ICs 30 and 31 to provide select signals for each 4K byte block of memory starting at any 4K boundary. These signals arrive at pins 1 to 16 of SK1. Pin 20 of SK1 provides the M.EXT signal which is necessary to decode the internal addressing of Nascom 1. This signal is not required by Nascom 2. Pins 17, 18 and 19 (SK1) are the memory array bank selects. These selects should be commoned to four of the 16 4K decodes. A0 to A7 are also routed to IC43 for Port decoding when "Page-mode" is used.

4. MEMORY CONTROL LOGIC MREQ is buffered by IC 27/3 and inverted by IC46/8. The output from IC46/8 is Anded (IC36/11) with the output from the 4Mhz Z80 precharge extender circuit (IC32) and is then inverted by IC46/10 (TP9-RAS). The RAS signal is then Ored in IC37/3/6/8 with the Anded bank decode and Refresh signals. When a memory bank is decoded only one RAS line to the memory array goes low. However, if a memory refresh is being performed, all the RAS inputs to the array will go low. The Active delay line (IC47), whose input is MREQ, goes low at pin 4 (MUX) approximately 60ns after MREQ goes active. All memory timing is referenced to MREQ. The 60ns delay was chosen to allow an adequate margin for the row address hold time. The signal controls the address multiplexers (IC33 & 34). Until now the memory array has been receiving the row addresses (A0 to A6). When MUX goes low the

column addresses (A7 to A13) are then switched to the array address inputs. After a further delay of approximately 30ns the delay line goes low at Pin 11 (CAS). This signal is then Ored in IC37/11 with RFSH. If a refresh is not being performed the memory array will receive CAS. It is necessary to delay CAS from MUX in order to allow the addresses to stabilise after being switched. When CAS is received the memory then latches the column addresses.

5. READ and WRITE LOGIC The WR signal is buffered in IC27/7 and is then Ored with the output of the card page mode WREN circuitry (TP10). This line is taken to the common terminal of LK5. If page mode is not installed then LK5/C should be connected to LK5/1 (+5v). This will permanently enable write enable. However, if page mode is installed, this link should be connected the other way round (LK5/C to LK5/2). This connects the WREN signal to the page mode circuitry and only when the card is paged in, will WREN be enabled. This signal is active high. The combined WR and WREN signal is then further Ored within the remaining three gates of IC38 with the memory bank write protect signals from IC40/4,7 & 9. The outputs of IC38 are taken to the memory array WR inputs via 3 33R resistors within RP1. The WR inputs to the memory array also appear at TP6,7 & 8 where they are marked WR 0 - 2 on the PCB. The write protect switches are supplied with the page mode kit (SW 1 - 3) so when the card is not used in page mode it is necessary to install 3 links, one in each of the switch pads; as shown in Fig.3 Because these write protect inputs are fully buffered, it is possible to have SW 1 - 3 mounted in a remote site not too far away from the card and connected to the 3 pads of each switch. The RD input is buffered in IC39/4 which appears at an input of IC35/8. The other inputs to this gate are MREQ, decode and card RDEN. The output of the gate when active enables the data output buffer IC25 and will bring Nasbus DBDR low. The memory will output data when addressed only when its write inputs are not active. (For further information on the memory chips, refer to Mostek's data sheet on the MK4116). The card RDEN (TP11) signal is similar to the previously mentioned WREN signal. When page mode is not installed, it is necessary to link LK6/C to LK6/2. LK6/C should be linked to LK6/1 if page mode is installed.

6. PAGE MODE and write protect upgrade kit. IC43 decodes the port (port FF) and is Ored with WR in IC44/3. This signal is subsequently Ored with IORQ which is used as a clock to latch data into IC45. The outputs from IC45 will all be low on power-up as the system reset is connected to the master reset input of this IC. Also on power-up, IC40/13 will be high bringing IC44/8 & 11 high. SW4 is a four position di1 switch which selects the card page number. If in position 0 as marked

on the PCB, the card will become active on power-up and up until such time as the port status changes. By changing the data of port FF one card can be paged out and another paged into the system. Because of this method of paging it is possible to enable one card to read only and another to write only; so by allowing the processor to read and write to the same address, data will be transferred from one page to another. This illustrates only one of many ways in which the page mode facility can be used. The page on LED (LED4) will be lit up when a page is read enabled. LED1, 2 & 3 will be lit if the write protect switch is in its protect position. These LEDs are driven by IC42 which is a five NPN transistor array. The fifth transistor in this package is used to provide Nasbus with an IO/EXT signal. When page mode is not installed, LK7 should not be present. Nasbus lines 46 to 48 are brought onto the card to allow the facilities of the page mode to be extended at a later date.

7. SUGGESTED NASCOM MEMORY MAP

0000 to 07FF Existing operating system

0800 to 0BFF Existing video RAM

0C00 to 0C7F Existing operating system workspace

0C80 to 0CFF Extended operating system workspace

0D00 to 0F7F Workspace for firmware or workspace for programs

0F80 to 0FFF Usual stack space

1000 to 8FFF General RAM space. Start of general program space

9000 to 9FFF Programmable graphics RAM or general RAM space

9800 to AFFF Colour graphics RAM or general RAM space

B000 to B7FF Extensions to the operating system or extensions to Naspen

B800 to BFFF Naspen or related word processing software

C000 to CFFF Revas or general disassembler software or Colour graphics control software


Memory map continued...

D000 to DFFF or general assembler type software or extensions to Basic

E000 to FFFF 8K Basic


8. MEMORY ARRAY SUPPLY LINKS (LK1 to 3) These three links are provided to enable memories other than type MK4116 to be used on the board. This includes new memories not yet available such as Pseudo-Static devices. If this type of device is used in the future, some makes may require the Z80 refresh signal at pin 1. In this case change LK 3 (c to 1) and remove tantalum capacitors C80, 81 and 82. Check the supply requirements for these devices and change LK1 and 2 where appropriate

fig.5 Links 1 to 3




The above links 1 to 3 are shown in the correct position for use with MK4116 Dynamic memory, as supplied with the kit.

9. PAGE MODE LINKS (LK5 to 6)




10. ADDRESSING LINK OPTIONS

fig.7 SK1 Address decode

0000-0FFF	1		20	N1 M.EXT
1000-1FFF	2		19	BANK 0 (ICs 1 to 8)
2000-2FFF	3		18	BANK 1 (ICs 9 to 16)
3000-3FFF	4		17	BANK 2 (ICs 17 to 24)
4000-4FFF	5		16	F000-FFFF
5000-5FFF	6		15	E000-EFFF
6000-6FFF	7		14	D000-DFFF
7000-7FFF	8		13	C000-CFFF
8000-8FFF	9		12	B000-BFFF
9000-9FFF	10		11	A000-AFFF

A link between pin 1 and 20 is only requisite if the memory card is to be used in a Nascom 1 system.

fig.8 Suggested link options.




11. References

1. Z80 CPU Technical manual
2. Nasbus functional specification. Issue 7.
3. MOSTEK MK4116 RAM data sheet
4. Nascom 1 constructional notes
5. Nascom 2 constructional notes
6. Nascom Buffer card specification.
7. MOSTEK Z80 Dynamic RAM interface application note.

This documentation was prepared on the NAS-PEN Text processor.

Fig. 10 Memory control logic




NASCOM microcomputers Ltd.
 92 Broad Street, Chesham, Bucks.

type (b) RAM board [1]

drawn	NM no. 024-400	date 22-04-80	issue
checked			
			2

- C32: S74
- C35: S20
- C36: S30
- C37: S32
- C39: S06
- C41: 08
- C46: LS 04
- AD1: 54-018

Fig. 12 Memory array



ICs 1-24: 4116-3 or -4
dynamic memory array

NASCOM microcomputers Ltd.
92 Broad Street, Chesham, Bucks.

type (b) RAM board [3]

NM no. 024-402 | date 22-04-80 | issue
drawn *ds* | checked NB

2